



OPENING THE CABIN DOOR

Because the cabin door is heavy, you can easily twist your back if you do not use a wide stance. The path the door follows when you open and close it, means that you must have a wide reach in order to move with it. To get a wide reach keep your feet wide apart with your knees slightly bent. That way your legs take up the motion instead of your back!